


## Y/隔板



型号	A	适用型号
Y20	10	AC2000,AC2010
Y30	11	AC3000,AC3010
Y40	14	AC4000,AC4010

### Y20/30/40

■ 隔板




## Y-L/隔板连L型托架



隔板连L型托架	A	B	C	D	E	F	G	R	L	适用型号
Y20L	24	15	5.5	3	30	5	10	2.75	33	AC2000
Y30L	35	16	7	4	41	7	11	3.5	45	AC3000
Y40L	40	22	9	4	50	7	14	4.5	50	AC4000

### Y-L20/30/40

■ 隔板连L型托架




## Y-T/隔板连T型托架



隔板连T型托架	A	B	C	D	E	F	G	R	L	适用型号
Y20T	24	15	5.5	3	30	5	10	2.75	33	AC2000
Y30T	35	16	7	4	41	7	11	3.5	45	AC3000
Y40T	40	22	9	4	50	7	14	4.5	50	AC4000

### Y-T20/30/40

■ 隔板连T型托架



辅助  
元件




## B-A/托架



型号	A	B	C	D	F	G	H	J	K	L	N	R	T	适用型号
B240A	53	40	25	19	49.5	30	32	19.5	6	11.4	5.4	2.7	2.3	AR2000,AW2000
B340A	53	40	21	13.5	66	41	42.5	25	1.5	8	6.5	3.25	2.3	AR3000,AW3000
B440A	70	54	27	18	80	50	52.5	30	2	10.5	8.5	4.25	2.3	AR4000,AW4000

### B240/340/440A

■ 托架



辅助  
元件


## B-B/托架



型号	A	B	C	D	F	H	J	L	M	N	T	适用型号
B240B	40	27	33	27	17.4	4.5	24	8.4	14	5.4	2.3	AF2000,AL2000
B340B	53	40	39	32	25.6	4.5	35	8	19	6.5	2.3	AF3000,AL3000
B440B	70	54	47	38	31.5	5.5	47	10.5	20	8.5	2.3	AF4000,AL4000

### Y-L20/30/40

■ 隔板连L型托架



## G40/50/压力表



型号	压力范围 (MPa)	适用型号	重量 (g)
G40-10-01	MAX.1.0	2000,3000 Series	56g
G50-10-02		4000 Series	80g

### Y-T20/30/40

■ 隔板连T型托架



▷ G40-10-01

▷ G50-10-02

